

Hose does not reel in

A number of different causes are possible

- Hose stuck
 - Check that the reel is moving freely by manually turning it
- [Hose grows on reel](#)
- Chain has jumped off
- Motor is broken
 - Check if PLB software is 1.17 or above (softer motor drive)
- Motor cable is damaged

Also check points listed for [hose reel stuck alarm](#).

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/troubleshooting:no_alarm:hose_does_not_reel_in

Last update: **2023/05/24 05:06**

