

Low battery capacity

Lead acid batteries have a limited lifespan and loose capacity over time. Not charging correctly, repeatedly deep discharging, storing batteries uncharged etc. will shorten the lifespan drastically. It is also important to keep the battery top clean.

[Read more about battery maintenance](#)

Troubleshooting

- Check battery voltage for each battery separately when fully charged. Fully charged the total open circuit voltage should be above 12.6 V (2.1 V per cell).
 - A fully charged battery voltage around 10 V indicates a dead cell and battery needs replacement
 - Open circuit voltage is measured correctly when robot has been left disconnected from charger and powered off for at least 1 hour
- Check condition of the battery poles and connectors. They should be kept clean for good electrical conduction.
- Check that the 3 battery cables and their terminals are not damaged
- Check condition of charging connectors, poor electrical conduction affects charging
- Check the battery [specification](#)

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/troubleshooting:no_alarm:low_battery_capacity

Last update: **2025/01/06 03:07**

