Problem with motor

Description

Motor issues can arise from a number of reasons:

- Damaged cables leading to circuit breaks or short circuits
- Damaged connectors or water ingress in connectors
- Bad connection in connectors
- Damaged gears
- Overheated motor

Troubleshooting

Always troubleshoot the motor from the Manual screen. Run it at least 5 seconds in each direction. Press the “i” button for a detailed view. If the robot gives an alarm, check the troubleshooting guide for that specific alarm.

- Does the position counter change? If not, check the pulse signal and power cables.
- Does the function move physically? If not:
  - Does any sound come from the motor? If it does, the function could be physically stuck or the gear can be damaged. No sound? Check cables
  - Does the motor draw any current? If not, check the cables.
- Check that the emergency stop button is not pressed down
- Spray connectors with 5-56 or WD-40
- If you have access to a spare motor you can connect it temporarily to the connector in order to troubleshoot the function. Remember to ground it properly, e.g. by holding a motor metal part against robot chassie.

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/troubleshooting:no_alarm:motor_problem?rev=1694702021

Last update: **2023/09/14 07:33**